

The rubber camera-mount for the SUV-Cam

Instruction manual

Please read this instruction manual carefully before using this product and keep it for future reference.

Important safeguards

Please make sure to follow all instructions when you use the camera-mount. These "Important safeguards" are provided to ensure proper operation of the product and will prevent you or others from personal injury or loss of assets. Please read carefully and keep the manual in a safe place for future reference. Review the following symbols so that you understand them before reading the rest of the manual.



Warning

Ignoring this warning and operating the system incorrectly subjects the user to possible risk of serious injury or death.



Caution

Ignoring this warning and operating the system incorrectly subjects the user to possible risk of injury or loss of assets.

● Explanation of the Symbols Used



Name : Caution
Explanation : The user must follow or be exposed to danger. Nearby text and illustrations give further details.



Name : Prohibition
Explanation : The user must avoid these actions or be exposed to danger. Nearby text and illustrations give further details.



Name : Must follow
Explanation : The user must follow the instructions. Nearby text and illustrations give further details.

ELMO CO., LTD.

ELMO are trademarks and/or registered trademarks of ELMO Co., Ltd.

URL: <http://www.elmo.co.jp>

Warning



Do not install the camera-mount in areas where salt erosion or corrosive gas is produced.

The camera-mount will be damaged and it may cause the camera to drop accidentally.



Do not attach any other objects than specified camera heads to the camera-mount.

Insufficient support strength due to improper size of object may cause the camera to drop accidentally leading to injury to persons nearby or damage to the object.



Install the camera-mount to a secure place.

Do not install the camera-mount to insecure places such as on a sticker or soft materials like clothes.



Inspect the camera-mount regularly.

Examine the conditions of installation before you use. Insufficient support strength may cause the camera to accidentally drop leading to injury to persons nearby.



Keep the camera-mount out of baby's reach

Small accessories could choke or injure a baby if swallowed. Contact a doctor immediately if this happens.



Do not modify the camera-mount.

Do not cut the camera-mount. It may cause the camera to accidentally drop leading to injury to persons nearby.

Caution



Do not clean the camera-mount with volatile solvents, such as thinner and benzene.

This may damage the quality of rubber material.



Do not let children play with the empty carton or bag.

It could choke or injure children.



Do not place the camera-mount near excessive heat or strong sunlight.

Excessive heat may cause the camera-mount to change shape causing the camera head to detach itself or to accidentally drop leading to injury to persons nearby.



Do not place the camera-mount prone to heavy vibration or strong acceleration.

This may cause the camera head or the cable to detach itself leading to injury to persons nearby.



Do not apply excessive force to the camera head or the cable attached to the holder.

This may cause the camera head or the cable to detach itself leading to injury to persons nearby.



Do not touch surface of the hook and loop fastener.

It may weaken the attachment of the fastener causing the camera-mount to easily detach itself.



Do not install the camera-mount to a wet surface. Do not use it under water.

It may weaken the attachment of the fastener causing the camera-mount to easily detach itself.

Applicable camera : SUV-Cam
Weight : Approx. 30 g

How to use

1. Remove dirt on the surface where the fastener is to be attached.


Remove dirt such as water, oil and dust on the surface of attachment.



Confirm that the fastener is attached to a smooth, flat surface.
Do not attach the fastener on uneven surfaces such as trees, skin and clothing.


2. Attach the hook and loop fastener.

Decide the position and direction of the fastener for the camera and cable holder. Consider the direction of the camera head to be attached then attach the fastener.




Do not touch surface of the hook and loop fastener.
Do not reuse the fastener once it has been removed.

3. Attach each holder to the hook and loop fastener.



Match fastener size with holder size.
Do not use any other fastener other than the one supplied.

4. Set the camera and cable to each holder.



Do not widen the gap too much. This may damage the camera-mount causing the camera head to detach itself.

5. Confirm that it has been attached firmly.

Confirm that it has been attached firmly under the conditions it will be used.